## Tracker

## How to set a tracker?

- 1. Find out the input frequency with a spectrum analyzer
- 2. Turn on the tracker 💛 (K+K counter and tracker have different pin assignments !)
- 3. Turn the gain down to 0
- 4. View the monitor output or A/B output frequency on the spectrum analyzer (Maybe too strong signal, dBm)
- 5. Turn the frequency by means of the VCO rotary knob to the required frequency
- 6. **Now** plug in the RF signal in the RF signal input
- 7. Turn the gain up until you can see a better signal
- 8. Done

Controversial discussion: Some people use the integrator and some people not. Usually we don't use the integrator. If you want to use it, aktivate the integrator after step 7).

• If the tracker doesn't work, turn off and on the complete power supply.

From: https://iqwiki.iqo.uni-hannover.de/ - **IQwiki** 

Permanent link: https://iqwiki.iqo.uni-hannover.de/doku.php?id=groups:mg:tracker&rev=147578632

Last update: 2016/10/06 20:38

