


# Net View

## “Connection”-window:

“GPS receiver”-button must be selected.


Push “connect”-button.




## “Receiver”-window:

The “Measurements”-button/setting shows the coordinates of the satellites.

The “Skyplot”-button/setting shows the connections with the satellites and the names.



You can change the reference frequency from "Empfänger 1" under "**Parameter**"-window → "Advanced"-button → "External frequency"-button.



From:

<https://iqwiki.iqo.uni-hannover.de/> - IQwiki

Permanent link:

<https://iqwiki.iqo.uni-hannover.de/doku.php?id=groups:mg:netview&rev=1474200441>

Last update: **2016/09/18 12:07**

