2025/07/05 13:16 1/3 failurechecklist

# **Checklist after power failure**



If you know a power failure will come, than turn off everthing (without Meerstetter, IGP's and H-Maser)! And organise a lot of USV's

#### Check both IGP Controller for the resonators R1 + R2

- Current should be below 2 mA (both should show "HV ON" (green LED on)
- Check both USV for IGP'S

## Turn on the computers

#### Check Meerstetter TEC for R1 + R2 + ECDL

- Green LED on?
- Check in the software TEC Service v2.70 R1, TEC Service v2.70 R2 and TEC Service v2.70 -ECDL Baseplate on the ResLab-PC:
  - How is the behavior of the temperature?
- Check both USV for TEC's

## Check the air conditioner for the entire room

- Is the air-conditioning system switched on?
  - o Is the V-belt (=Keilriemen) broken?
- What is the temperature of the draft (=Zugluft)? → should be >20 °C
  - Check the electric fuse (=Sicherung) on the third floor

## Check the H-Maser

- All LED are green?
- Check in the Software VCH on the ResLabMobil:
  - All values except for D2h must be green!

## Check the 914nm-laser

- Light is on? Powermodule is on?
- TA stabilization is ok?
- Laserdiode is on?
- How much power is in front of the resonator?  $\rightarrow$  should be 70-100  $\mu$ W
- What wavelength does the Wavemeter display?

## Check the 10 MHz reference and set all frequencies in the lab

GPS-Receiver is working?

- LED flashes orange/yellow?
  - If not Turn on the PWR switch until LED flashes
  - Start the software Net View and connect the receiver (COM Port2)
- Rb-clock is working?
  - Check the LED's:
    - Power-LED and Locked-LED have to be green
    - 1 pps sync-LED has to be green
    - 1 pps input-LED has to flash
  - Check the 10 MHz-frequency output with an spectrum analyzer, if there is 10 MHz.
- Check the 10 MHz distributor synthesizer
  - Ext refernce 10 MHz direct is working?
  - Set correct values
- Check all other synthesizer
  - Ext refernce 10 MHz direct is working?
  - Set correct values

## **Check frequency comb**

- Laser and amplifier are on?
  - Check LED's
- Do the software fiber laser and fiber comb control work?
  - Can you speak with the comb?

#### Check the counter

- Does the software FXQE80 work?
- If not: Turn off and on the counter (cold-device plug disconnect and connect)

#### Check the fiber Link to PTB

- Turn everthing on, like ther spectrum analysizer
- Restart the PC in the Atom Lab
- Call them!

## If the temperature is normal again, then...

- Stabilize the laser of R1
  - 1. Turn on the Laserdiode
  - 2. Turn on the TA
  - 3. Couple the light into the TA
  - 4. Turn on the TA stabilization
  - 5. Lock R1
- 2. Stablize the frequency comb
  - 1. Lock Ceo

- 2. Lock Rep
- 3. Measure the frequencies with the counter:
  - 1. 914nm
  - 2. frep
  - 3. 10 MHz
  - 4. virtuel beat

From:

https://iqwiki.iqo.uni-hannover.de/ - IQwiki

Permanent link:

https://iqwiki.iqo.uni-hannover.de/doku.php?id=groups:mg:failurechecklist&rev=1484298320

Last update: 2017/01/13 09:05

